

## Standard

**PCS** **Parts counting:** reference quantities selectable. Display can be switched from piece to weight.

**IP 54** **Spray and dust protection:** protection class is indicated in the symbol.

**M**  
Verification Possible

**DKD**  
Certificate Possible

**3**  
Warranty Years

**PCS** **IP 54**  
Standard

## Counting Balance VC

Verifiable industry model for professional counting and weighing



**Six memories**  
for reference weights

**Weight display**

**Reference weight**  
in kg / 1000 Stück

**Input via numerical keypad**

- Preliminary subtraction of tare weight
- Reference piece quantity
- Reference weight

### Precise counting

Step by step the automatic reference optimisation can improve the average value of the piece weight

### Battery supply possible

Batteries size D (6 x 1.5 V) not standard. Service life approx. 500 h. With AUTO-OFF function to preserve the battery, selectable between 3, 10, 30, 60, 180 min

**High mobility** thanks to battery supply



Model	Read-out	Weighing range	Verification value	Minimum load	Minimum piece weight at parts counting
	<b>d</b>	<b>Max</b>	<b>e</b>	<b>Min</b>	
KERN	g	kg	g	g	g
VC 3 K1M	<b>1</b>	3	1	20	0.1
VC 6 K2M	<b>1</b>	6	2	40	0.2
VC 15 K5M	<b>1</b>	15	5	100	0.5
VC 30 K10M	<b>1</b>	30	10	200	1

**1** Verification in the factory, location of use with post code required, additional costs. Total balance W x D x H 345 x 370 x 120 mm. Net weight approx. 4.4 kg. Permissible ambient temperature -10 ... +40°C.

## DKD Calibration Certificates

DKD = German Calibration Service

KERN issues in its own accredited laboratories internationally valid DKD Calibration Certificates ...

- for balances
- for test weights

KERN is a manufacturer of test weights in all OIML classes of accuracy E<sub>1</sub>, E<sub>2</sub>, F<sub>1</sub>, F<sub>2</sub>, M<sub>1</sub>-M<sub>3</sub>, from 1 mg to 2000 kg

## KERN - Your DKD Calibration Partner

## Your specialist dealer

KERN & Sohn GmbH, D-72322 Balingen, Postbox 4052  
 Tel. 00 49-[0]74 33-99 33-0 Fax 00 49-[0]74 33-99 33-149  
 e-mail: info@kern-sohn.de Internet: www.kern-sohn.com

